

Produktveiledning

takstativ



Bilmerke	Modell	Karosseri	Årsmodell		Takräcke – Stål		Takräcke – Alu	
			FRA:	TIL:	MODELL	ART.NR.	MODELL	ART.NR.
Alfa Romeo	156 Crosswagon	5dr Kombi	1998	2006	RF20	002533	RF20Alu	002543
Alfa Romeo	156 Crosswagon	5dr Kombi	1998	2006	RF20	002533	RF20Alu	002543
Alfa Romeo	159 Sportwagon	5dr Kombi	2006	on	RF20	002533	RF20Alu	002543
Audi	100 Avant	5dr Kombi	1991	1995	RF20	002533	RF20Alu	002543
Audi	100 Avant	5dr Kombi	1982	1991	RF20	002533	RF20Alu	002543
Audi	200 Avant	5dr Kombi	1982	1991	RF20	002533	RF20Alu	002543
Audi	80 Avant	5dr Kombi	1992	1996	RF20	002533	RF20Alu	002543
Audi	A3 Sportback	5dr Halvkombi	2004	2012	RF23	002548	RF23Alu	002535
Audi	A3 Sportback	5dr Halvkombi	2012	on	RF23	002548	RF23Alu	002535
Audi	A4 Allroad	5dr Kombi	2015	on	RF20	002533	RF20Alu	002543
Audi	A4 Allroad	5dr Kombi	2009	2015	RF20	002533	RF20Alu	002543
Audi	A4 Avant	5dr Kombi	2008	2015	RF23	002548	RF23Alu	002535
Audi	A4 Avant	5dr Kombi	1996	2001	RF20	002533	RF20Alu	002543
Audi	A4 Avant	5dr Kombi	2001	2004	RF20	002533	RF20Alu	002543
Audi	A4 Avant	5dr Kombi	2004	2008	RF20	002533	RF20Alu	002543
Audi	A6 ALL ROAD	5dr 4x4	2008	2011	RF20	002533	RF20Alu	002543
Audi	A6 ALL ROAD	5dr 4x4	2000	2007	RF20	002533	RF20Alu	002543
Audi	A6/S6 Avant	5dr Kombi	1994	1998	RF20	002533	RF20Alu	002543
Audi	A6/S6 Avant	5dr Kombi	1998	2004	RF20	002533	RF20Alu	002543
Audi	A6/S6 Avant	5dr Kombi	2005	2011	RF23	002548	RF23Alu	002535
Audi	A6/S6 Avant	5dr Kombi	2011	on	RF23	002548	RF23Alu	002535
Audi	Q3	5dr SUV	2011	on	RF23	002548	RF23Alu	002535
BMW	3 Series Touring	5dr Kombi	2005	2012	RF20	002533	RF20Alu	002543
BMW	3 Series Touring	5dr Kombi	1995	1999	RF20	002533	RF20Alu	002543
BMW	3 Series Touring	5dr Kombi	1999	2005	RF20	002533	RF20Alu	002543
BMW	5 Series Touring	5dr Kombi	1997	2004	RF20	002533	RF20Alu	002543
BMW	5 Series Touring	5dr Kombi	2004	2010	RF20	002533	RF20Alu	002543
BMW	X3	5dr 4x4	2004	2010	RF20	002533	RF20Alu	002543
BMW	X5	5dr 4x4	2000	2007	RF20	002533	RF20Alu	002543
BMW	X5	5dr 4x4	2007	2013	RF20	002533	RF20Alu	002543
Cadillac	SRX	5dr SUV	2004	2009	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Astro Van	Van			RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Aveo	5dr Kombi	2008	on	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Blazer	5dr 4x4	1994	2004	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Captiva	5dr SUV	2006	2012	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Captiva	5dr SUV	2013	on	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Cruze	5dr Kombi	2012	on	RF20	002533	RF20Alu	002543

Bilmerke	Modell	Karosseri	Årsmodell		Takräcke – Stål		Takräcke – Alu	
			FRA:	TIL:	MODELL	ART.NR.	MODELL	ART.NR.
Chevrolet (Daewoo)	Lacetti	5dr Kombi	2004	on	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Matiz	5dr Halvkombi	1998	2005	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Musso	5dr 4x4	1999	2002	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Nubira	5dr Kombi	1997	2002	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Nubira	5dr Kombi	2004	2005	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Rezzo	5dr Halvkombi	2001	on	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Spark	5dr Halvkombi	2010	on	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Tacuma	MPV	2000	2008	RF20	002533	RF20Alu	002543
Chevrolet (Daewoo)	Trans Sport	MPV	1997	on	RF20	002533	RF20Alu	002543
Chrysler	300C	5dr Kombi	2006	2010	RF20	002533	RF20Alu	002543
Citroën	Berlingo Multispace / Top	MPV	2002	2008	RF20	002533	RF20Alu	002543
Citroën	C Crosser	5dr SUV	2007	on	RF20	002533	RF20Alu	002543
Citroën	C3	5dr Halvkombi	2004	2009	RF20	002533	RF20Alu	002543
Citroën	C3 Picasso	MPV	2009	on	RF20	002533	RF20Alu	002543
Citroën	C3 X-TR	MPV	2004	2008	RF20	002533	RF20Alu	002543
Citroën	C5	5dr Kombi	2001	2004	RF20	002533	RF20Alu	002543
Citroën	C5	5dr Kombi	2004	2008	RF20	002533	RF20Alu	002543
Citroën	C5	5dr Kombi	2008	on	RF20	002533	RF20Alu	002543
Citroën	C5 CrossTourer	5dr Kombi	2014	on	RF20	002533	RF20Alu	002543
Citroën	XM	5dr Kombi	1991	1999	RF20	002533	RF20Alu	002543
Citroën	ZX	5dr Kombi	1994	1998	RF20	002533	RF20Alu	002543
Dacia	Duster	5dr 4x4	2010	2013	RF20	002533	RF20Alu	002543
Dacia	Logan MCV	MPV	2004	2008	RF20	002533	RF20Alu	002543
Dacia	Logan MCV	MPV	2009	2012	RF20	002533	RF20Alu	002543
Dacia	Logan MCV	MPV	2013	on	RF20	002533	RF20Alu	002543
Dacia	Sandero Stepway	5dr Halvkombi	2009	2012	RF20	002533	RF20Alu	002543
Dacia	Sandero Stepway	5dr Halvkombi	2013	on	RF20	002533	RF20Alu	002543
Fiat	Croma	5dr Kombi	2005	2007	RF20	002533	RF20Alu	002543
Fiat	Doblo	MPV	2001	2008	RF20	002533	RF20Alu	002543
Fiat	Idea	5dr Halvkombi	2004	2007	RF20	002533	RF20Alu	002543
Fiat	Marea Weekend	5dr Kombi	1997	2002	RF20	002533	RF20Alu	002543
Fiat	Palio Weekend	5dr Kombi	1998	on	RF20	002533	RF20Alu	002543
Fiat	Panda	5dr Halvkombi	2004	2011	RF20	002533	RF20Alu	002543
Fiat	Sedici	5dr 4x4	2006	2008	RF20	002533	RF20Alu	002543
Fiat	Stilo Multiwagon	5dr Kombi	2003	2007	RF20	002533	RF20Alu	002543
Fiat	Tempra	5dr Kombi	1990	1993	RF20	002533	RF20Alu	002543
Fiat	Tempra	5dr Kombi	1993	1996	RF20	002533	RF20Alu	002543

Bilmerke	Modell	Karosseri	Årsmodell		Takräcke – Stål		Takräcke – Alu	
			FRA:	TIL:	MODELL	ART.NR.	MODELL	ART.NR.
Fiat	Uno	5dr Kombi	1990	2000	RF20	002533	RF20Alu	002543
Fiat	Uno	5dr Kombi	1983	1990	RF20	002533	RF20Alu	002543
Ford	Aerostar	VAN	1990	1997	RF20	002533	RF20Alu	002543
Ford	Escort	5dr Kombi	1990	1995	RF20	002533	RF20Alu	002543
Ford	Escort	5dr Kombi	1995	2000	RF20	002533	RF20Alu	002543
Ford	Focus	5dr Kombi	1998	2004	RF20	002533	RF20Alu	002543
Ford	Focus	5dr Kombi	2008	2011	RF20	002533	RF20Alu	002543
Ford	Galaxy	MPV	1995	2006	RF20	002533	RF20Alu	002543
Ford	Granada	5dr Kombi	1992	1995	RF20	002533	RF20Alu	002543
Ford	Kuga	5dr SUV	2008	2012	RF20	002533	RF20Alu	002543
Ford	Maverick	3dr 4x4	1993	2003	RF20	002533	RF20Alu	002543
Ford	Maverick	5dr 4x4	1993	2003	RF20	002533	RF20Alu	002543
Ford	Mondeo	5dr Kombi	1993	2000	RF20	002533	RF20Alu	002543
Ford	Mondeo	5dr Kombi	2000	2007	RF20	002533	RF20Alu	002543
Ford	Mondeo	5dr Kombi	2007	2014	RF20	002533	RF20Alu	002543
Ford	Scorpio	5dr Kombi	1995	1999	RF20	002533	RF20Alu	002543
Ford	Sierra	5dr Kombi	1982	1987	RF20	002533	RF20Alu	002543
Ford	Sierra	5dr Kombi	1987	1993	RF20	002533	RF20Alu	002543
Ford	Tourneo Connect	MPV	2008	on	RF20	002533	RF20Alu	002543
Ford	Windstar	MPV			RF20	002533	RF20Alu	002543
Honda	Accord Aerodeck	5dr Kombi	1994	1998	RF20	002533	RF20Alu	002543
Honda	Accord Aerodeck	5dr Kombi	1998	2003	RF20	002533	RF20Alu	002543
Honda	Accord Aerodeck	5dr Kombi	1991	1994	RF20	002533	RF20Alu	002543
Honda	Accord Aerodeck/Tourer	5dr Kombi	2003	2008	RF20	002533	RF20Alu	002543
Honda	Accord Aerodeck	5dr Kombi	2008	on	RF20	002533	RF20Alu	002543
Honda	Civic Aerodeck	5dr Kombi	1998	2001	RF20	002533	RF20Alu	002543
Honda	Civic Shuttle	5dr Kombi	1988	1995	RF20	002533	RF20Alu	002543
Honda	Civic Shuttle	5dr Kombi	1995	2000	RF20	002533	RF20Alu	002543
Honda	CRV	5dr 4x4	1997	2002	RF20	002533	RF20Alu	002543
Honda	Shuttle	5dr Halvkombi	1994	2001	RF20	002533	RF20Alu	002543
Hyundai	Atos +	5dr Halvkombi	1998	2001	RF20	002533	RF20Alu	002543
Hyundai	Getz Cross	5dr Halvkombi	2007	2009	RF20	002533	RF20Alu	002543
Hyundai	I30	5dr Kombi	2007	2012	RF20	002533	RF20Alu	002543
Hyundai	Lantra	5dr Kombi	1996	2001	RF20	002533	RF20Alu	002543
Hyundai	Matrix	MPV	2002	2010	RF20	002533	RF20Alu	002543
Hyundai	Santa FE	5dr 4x4	2001	2006	RF20	002533	RF20Alu	002543
Hyundai	Santa FE	5dr 4x4	2009	2012	RF20	002533	RF20Alu	002543

Bilmerke	Modell	Karosseri	Årsmodell		Takrücke – Stål		Takrücke – Alu	
			FRA:	TIL:	MODELL	ART.NR.	MODELL	ART.NR.
Hyundai	Trajet	MPV	2000	2006	RF20	002533	RF20Alu	002543
Hyundai	Tucson	MPV	2004	2009	RF20	002533	RF20Alu	002543
Infiniti	FX35	5dr Halvkombi	2003	on	RF20	002533	RF20Alu	002543
Jaguar	X Type	5dr Kombi	2004	2010	RF20	002533	RF20Alu	002543
Jeep	Cherokee	5dr 4x4	2001	2008	RF20	002533	RF20Alu	002543
Jeep	Grand Cherokee	5dr 4x4	1999	2005	RF20	002533	RF20Alu	002543
Kia	Carens	MPV	2000	2006	RF20	002533	RF20Alu	002543
Kia	Cee'd	5dr Kombi	2007	2012	RF20	002533	RF20Alu	002543
Kia	Clarus	5dr Kombi	1998	2001	RF20	002533	RF20Alu	002543
Kia	Joice	5dr Kombi	2000	on	RF20	002533	RF20Alu	002543
Kia	Pride	5dr Kombi	1999	2001	RF20	002533	RF20Alu	002543
Kia	Rio	5dr Halvkombi	2001	2005	RF20	002533	RF20Alu	002543
Kia	Sorento	5dr 4x4	2003	2009	RF20	002533	RF20Alu	002543
Kia	Sorento	5dr 4x4	2009	2015	RF20	002533	RF20Alu	002543
Kia	Soul	5dr Halvkombi	2008	2013	RF20	002533	RF20Alu	002543
Kia	Sportage	5dr 4x4	1995	2003	RF20	002533	RF20Alu	002543
Kia	Sportage	5dr 4x4	2005	2010	RF20	002533	RF20Alu	002543
Lada	111 / VAZ 2111	5dr Kombi	1996	on	RF20	002533	RF20Alu	002543
Lancia	Lybra SW	5dr Kombi	1999	on	RF20	002533	RF20Alu	002543
Land Rover	Freelander	3dr 4x4	1997	2006	RF20	002533	RF20Alu	002543
Land Rover	Freelander St Wagon	3dr 4x4	1997	2006	RF20	002533	RF20Alu	002543
Lexus	RX	5dr 4x4	2009	on	RF20	002533	RF20Alu	002543
Lexus	RX300	5dr 4x4	2003	2009	RF20	002533	RF20Alu	002543
Mazda	5	5dr Kombi	2005	2010	RF20	002533	RF20Alu	002543
Mazda	6	5dr Kombi	2002	2007	RF20	002533	RF20Alu	002543
Mazda	6	5dr Kombi	2008	2012	RF20	002533	RF20Alu	002543
Mazda	6	5dr Kombi	2012	on	RF20	002533	RF20Alu	002543
Mazda	626	5dr Kombi	1988	1992	RF20	002533	RF20Alu	002543
Mazda	626	5dr Kombi	1992	1997	RF20	002533	RF20Alu	002543
Mazda	626	5dr Kombi	1998	2002	RF20	002533	RF20Alu	002543
Mazda	Demio	5dr Kombi	1998	2003	RF20	002533	RF20Alu	002543
Mazda	MPV	MPV	1999	2002	RF20	002533	RF20Alu	002543
Mazda	MPV	MPV	2003	2006	RF20	002533	RF20Alu	002543
Mazda	Premacy	MPV	1999	2004	RF20	002533	RF20Alu	002543
MercedesBenz	200T-300T	5dr Kombi	1976	1985	RF20	002533	RF20Alu	002543
MercedesBenz	200T-300T E Class	5dr Kombi	1986	1996	RF20	002533	RF20Alu	002543
MercedesBenz	B Class	5dr Halvkombi	2005	2007	RF20	002533	RF20Alu	002543

Bilmerke	Modell	Karosseri	Årsmodell		Takräcke – Stål		Takräcke – Alu	
			FRA:	TIL:	MODELL	ART.NR.	MODELL	ART.NR.
MercedesBenz	C Class	5dr Kombi	1996	2000	RF20	002533	RF20Alu	002543
MercedesBenz	C Class	5dr Kombi	2001	2008	RF20	002533	RF20Alu	002543
MercedesBenz	C Class	5dr Kombi	2008	2013	RF20	002533	RF20Alu	002543
MercedesBenz	E Class	5dr Kombi	1996	2003	RF20	002533	RF20Alu	002543
MercedesBenz	E Class	5dr Kombi	2002	2009	RF20	002533	RF20Alu	002543
MercedesBenz	E Class	5dr Kombi	2009	2016	RF20	002533	RF20Alu	002543
MercedesBenz	E200-320 T	5dr Kombi	1986	1996	RF20	002533	RF20Alu	002543
MercedesBenz	GLK	5dr 4x4	2008	2015	RF20	002533	RF20Alu	002543
MercedesBenz	Vaneo	MPV	2002	2003	RF20	002533	RF20Alu	002543
MG	ZT Touring	5dr Kombi	2001	2005	RF20	002533	RF20Alu	002543
Mitsubishi	Galant	5dr Kombi	1997	2003	RF20	002533	RF20Alu	002543
Mitsubishi	Lancer	5dr Kombi	1993	1998	RF20	002533	RF20Alu	002543
Mitsubishi	Outlander	5dr 4x4	2004	2007	RF20	002533	RF20Alu	002543
Mitsubishi	Outlander	5dr 4x4	2007	2012	RF20	002533	RF20Alu	002543
Mitsubishi	Pajero	5dr 4x4	2000	on	RF20	002533	RF20Alu	002543
Mitsubishi	Pajero Pinin	5dr 4x4	1999	on	RF20	002533	RF20Alu	002543
Mitsubishi	Pajero Sport	5dr 4x4	1998	2008	RF20	002533	RF20Alu	002543
Mitsubishi	Pajero Sport	5dr 4x4	2008	on	RF20	002533	RF20Alu	002543
Mitsubishi	Shogun	5dr 4x4	2000	2007	RF20	002533	RF20Alu	002543
Mitsubishi	Shogun Pinin	3dr 4x4	2000	2005	RF20	002533	RF20Alu	002543
Mitsubishi	Shogun Pinin	5dr 4x4	2000	2005	RF20	002533	RF20Alu	002543
Mitsubishi	Space Runner	MPV	1991	1999	RF20	002533	RF20Alu	002543
Mitsubishi	Space Star	MPV	1999	2005	RF20	002533	RF20Alu	002543
Mitsubishi	Space Wagon	MPV	1991	1998	RF20	002533	RF20Alu	002543
Mitsubishi	Space Wagon	MPV	1998	2003	RF20	002533	RF20Alu	002543
Nissan	Bluebird	5dr Kombi	1986	1990	RF20	002533	RF20Alu	002543
Nissan	Murano	5dr SUV	2005	on	RF20	002533	RF20Alu	002543
Nissan	Primera	5dr Kombi	1991	1998	RF20	002533	RF20Alu	002543
Nissan	Primera	5dr Kombi	1999	2002	RF20	002533	RF20Alu	002543
Nissan	Qashqai	5dr SUV	2007	2013	RF20	002533	RF20Alu	002543
Nissan	Qashqai + 2	5dr SUV	2008	2010	RF20	002533	RF20Alu	002543
Nissan	Qashqai + 2	5dr SUV	2010	on	RF20	002533	RF20Alu	002543
Nissan	Qashqai	5dr SUV	2014	on	RF20	002533	RF20Alu	002543
Nissan	Sunny	5dr Kombi	1992	1995	RF20	002533	RF20Alu	002543
Nissan	Terrano	3dr 4x4	1987	1993	RF20	002533	RF20Alu	002543
Nissan	Terrano	5dr 4x4	1987	1993	RF20	002533	RF20Alu	002543
Nissan	Terrano	3dr 4x4	1993	2001	RF20	002533	RF20Alu	002543

Bilmerke	Modell	Karosseri	Årsmodell		Takräcke – Stål		Takräcke – Alu	
			FRA:	TIL:	MODELL	ART.NR.	MODELL	ART.NR.
Nissan	Terrano	5dr 4x4	1993	2001	RF20	002533	RF20Alu	002543
Nissan	Xtrail	5dr SUV	2014	on	RF20	002533	RF20Alu	002543
Opel	Agila	5dr Halvkombi	2000	2008	RF20	002533	RF20Alu	002543
Opel	Antara	5dr SUV	2007	on	RF20	002533	RF20Alu	002543
Opel	Astra Caravan	5dr Kombi	1991	1998	RF20	002533	RF20Alu	002543
Opel	Astra Caravan	5dr Kombi	1998	2004	RF20	002533	RF20Alu	002543
Opel	Frontera Long	5dr 4x4	1993	1998	RF20	002533	RF20Alu	002543
Opel	Frontera Sport	5dr 4x4	1993	1998	RF20	002533	RF20Alu	002543
Opel	Kadett E Caravan	5dr Kombi	1985	1991	RF20	002533	RF20Alu	002543
Opel	Omega A Caravan	5dr Kombi	up to	1994	RF20	002533	RF20Alu	002543
Opel	Omega B Caravan	5dr Kombi	1994	2003	RF20	002533	RF20Alu	002543
Opel	Sintra	MPV	1996	1999	RF20	002533	RF20Alu	002543
Opel	Vectra Caravan	5dr Kombi	1996	2003	RF20	002533	RF20Alu	002543
Opel	Zafira	MPV	1999	2005	RF20	002533	RF20Alu	002543
Peugeot	305	5dr Kombi	1983	1989	RF20	002533	RF20Alu	002543
Peugeot	306	5dr Kombi	1997	2002	RF20	002533	RF20Alu	002543
Peugeot	405	5dr Kombi	1988	1997	RF20	002533	RF20Alu	002543
Peugeot	406	5dr Kombi	1997	2004	RF20	002533	RF20Alu	002543
Peugeot	1007	3dr Halvkombi	2005	2009	RF20	002533	RF20Alu	002543
Peugeot	2008	SUV	2013	on	RF20	002533	RF20Alu	002543
Peugeot	4007	5dr 4X4	2007	on	RF20	002533	RF20Alu	002543
Peugeot	206 SW	5dr Kombi	2002	2006	RF20	002533	RF20Alu	002543
Peugeot	207 SW	5dr Kombi	2007	on	RF20	002533	RF20Alu	002543
Peugeot	307 SW	5dr Kombi	2002	2007	RF20	002533	RF20Alu	002543
Peugeot	308 SW	5dr Kombi	2007	2013	RF20	002533	RF20Alu	002543
Peugeot	407 SW	5dr Kombi	2004	2011	RF20	002533	RF20Alu	002543
Porsche	Cayenne	MPV	2002	2009	RF20	002533	RF20Alu	002543
Renault	21 Navada	5dr Kombi	1986	1989	RF20	002533	RF20Alu	002543
Renault	21 Savanna	5dr Kombi	1986	1995	RF20	002533	RF20Alu	002543
Renault	Clio Sport Tourer	5dr Kombi	2008	2012	RF20	002533	RF20Alu	002543
Renault	Clio Sport Tourer	5dr Kombi	2013	on	RF20	002533	RF20Alu	002543
Renault	Koleos	5dr SUV	2008	2010	RF20	002533	RF20Alu	002543
Renault	Laguna	5dr Kombi	1995	2001	RF20	002533	RF20Alu	002543
Renault	Laguna	5dr Kombi	2001	2007	RF20	002533	RF20Alu	002543
Renault	Laguna	5dr Kombi	2007	2012	RF20	002533	RF20Alu	002543
Renault	Mégane	5dr Kombi	2003	2006	RF20	002533	RF20Alu	002543
Renault	Mégane	5dr Kombi	2006	2009	RF20	002533	RF20Alu	002543

Bilmerke	Modell	Karosseri	Årsmodell		Takräcke – Stål		Takräcke – Alu	
			FRA:	TIL:	MODELL	ART.NR.	MODELL	ART.NR.
Renault	Mégane Sport Tourer	5dr Kombi	2009	on	RF20	002533	RF20Alu	002543
Renault	Scenic	MPV	2009	on	RF20	002533	RF20Alu	002543
Rover	75	5dr Kombi	2000	2005	RF20	002533	RF20Alu	002543
Rover	Streetwise	3dr Halvkombi	2003	2005	RF20	002533	RF20Alu	002543
Rover	Streetwise	3dr Halvkombi	2003	2005	RF20	002533	RF20Alu	002543
Saab	9-3 SportWagon	5dr Kombi	2005	2009	RF20	002533	RF20Alu	002543
Saab	9-3 X (Black rails)	5dr Kombi	2009	2011	RF20	002533	RF20Alu	002543
Saab	9-5	5dr Kombi	1999	2002	RF20	002533	RF20Alu	002543
Saab	9-5	5dr Kombi	2002	2010	RF20	002533	RF20Alu	002543
Seat	Alhambra	MPV	1996	2010	RF20	002533	RF20Alu	002543
Seat	Altea FREETRACK	MPV	2007	2009	RF23	002548	RF23Alu	002535
Seat	Altea XL	MPV	2007	on	RF23	002548	RF23Alu	002535
Seat	Ateca	SUV	2016	on	RF20	002533	RF20Alu	002543
Seat	Exeo	5dr Kombi	2009	on	RF20	002533	RF20Alu	002543
Skoda	Fabia	5dr Kombi	2001	2007	RF20	002533	RF20Alu	002543
Skoda	Fabia	5dr Kombi	2007	2014	RF20	002533	RF20Alu	002543
Skoda	Fabia	5dr Kombi	2014	on	RF20	002533	RF20Alu	002543
Skoda	Felicia	5dr Kombi	1996	2001	RF20	002533	RF20Alu	002543
Skoda	Octavia	5dr Kombi	1998	2000	RF20	002533	RF20Alu	002543
Skoda	Octavia	5dr Kombi	2000	2004	RF20	002533	RF20Alu	002543
Skoda	Octavia	5dr Kombi	2004	2009	RF20	002533	RF20Alu	002543
Skoda	Octavia	5dr Kombi	2009	2012	RF20	002533	RF20Alu	002543
Skoda	Octavia	5dr Kombi	2013	on	RF20	002533	RF20Alu	002543
Skoda	Octavia Scout	5dr Kombi	2009	on	RF20	002533	RF20Alu	002543
Skoda	Praktik	MPV	2007	on	RF20	002533	RF20Alu	002543
Skoda	Roomster	5dr Kombi	2006	on	RF20	002533	RF20Alu	002543
Skoda	Scout	5dr Kombi	2006	on	RF20	002533	RF20Alu	002543
Skoda	Superb	5dr Kombi	2010	2015	RF20	002533	RF20Alu	002543
Ssangyong	Korando	5dr 4x4	2011	on	RF20	002533	RF20Alu	002543
Ssangyong	Kyron	5dr 4x4	2003	2007	RF20	002533	RF20Alu	002543
Ssangyong	Kyron	5dr 4x4	2007	on	RF20	002533	RF20Alu	002543
Ssangyong	Musso	5dr 4x4	1995	1999	RF20	002533	RF20Alu	002543
Ssangyong	Revlon	5dr Halvkombi			RF20	002533	RF20Alu	002543
Ssangyong	Rexton	5dr 4x4	2003	on	RF20	002533	RF20Alu	002543
Ssangyong	Rodius	5dr 4x4	2005	on	RF20	002533	RF20Alu	002543
Subaru	Forester	5dr 4x4	1997	2002	RF20	002533	RF20Alu	002543
Subaru	Forester	5dr 4x4	2008	2013	RF20	002533	RF20Alu	002543

Bilmerke	Modell	Karosseri	Årsmodell		Takrücke – Stål		Takrücke – Alu	
			FRA:	TIL:	MODELL	ART.NR.	MODELL	ART.NR.
Subaru	Impreza	5dr Kombi	1993	2000	RF20	002533	RF20Alu	002543
Subaru	Impreza	5dr Kombi	2001	2005	RF20	002533	RF20Alu	002543
Subaru	Legacy	5dr Kombi	1989	1994	RF20	002533	RF20Alu	002543
Subaru	Legacy	5dr Kombi	1994	1998	RF20	002533	RF20Alu	002543
Subaru	Legacy	5dr Kombi	1998	2003	RF20	002533	RF20Alu	002543
Subaru	Outback	5dr Kombi	1999	2004	RF20	002533	RF20Alu	002543
Suzuki	Baleno	5dr Kombi	1996	2002	RF20	002533	RF20Alu	002543
Suzuki	Forenza Wagon	5dr Kombi	2002	2008	RF20	002533	RF20Alu	002543
Suzuki	Grand Vitara	5dr 4x4	1998	2005	RF20	002533	RF20Alu	002543
Suzuki	Ignis	3dr Halvkombi	2001	2006	RF20	002533	RF20Alu	002543
Suzuki	Ignis	5dr Halvkombi	2001	2008	RF20	002533	RF20Alu	002543
Suzuki	Jimny	3dr 4x4	1998	on	RF20	002533	RF20Alu	002543
Suzuki	SX4	5dr SUV	2006	2012	RF20	002533	RF20Alu	002543
Suzuki	SX4	5dr SUV	2013	on	RF20	002533	RF20Alu	002543
Suzuki	Wagon R+	MPV	1998	2000	RF20	002533	RF20Alu	002543
Suzuki	Wagon R+	MPV	2000	2007	RF20	002533	RF20Alu	002543
Suzuki	Vitara	5dr 4x4	1994	1998	RF20	002533	RF20Alu	002543
Toyota	4 Runner	5dr 4x4	1993	1996	RF20	002533	RF20Alu	002543
Toyota	Avensis	5dr Kombi	1998	2003	RF20	002533	RF20Alu	002543
Toyota	Avensis	5dr Kombi	2003	2009	RF20	002533	RF20Alu	002543
Toyota	Avensis Verso	MPV	2001	2006	RF20	002533	RF20Alu	002543
Toyota	Camry	5dr Kombi	1992	1997	RF20	002533	RF20Alu	002543
Toyota	Carina	5dr Kombi	1988	1993	RF20	002533	RF20Alu	002543
Toyota	Carina E	5dr Kombi	1993	1998	RF20	002533	RF20Alu	002543
Toyota	Corolla	5dr Kombi	1987	1992	RF20	002533	RF20Alu	002543
Toyota	Corolla	5dr Kombi	1992	1997	RF20	002533	RF20Alu	002543
Toyota	Corolla	5dr Kombi	1997	2002	RF20	002533	RF20Alu	002543
Toyota	Corolla	5dr Kombi	2002	2004	RF20	002533	RF20Alu	002543
Toyota	Corolla Verso	MPV	2002	2004	RF20	002533	RF20Alu	002543
Toyota	Corolla Verso	MPV	2004	2009	RF20	002533	RF20Alu	002543
Toyota	Hilux	Pickup	2006	on	RF20	002533	RF20Alu	002543
Toyota	Hilux 4-Runner	Pickup	1990	1997	RF20	002533	RF20Alu	002543
Toyota	Landcruiser	3dr 4x4	1989	1998	RF20	002533	RF20Alu	002543
Toyota	Landcruiser	5dr 4x4	1989	1998	RF20	002533	RF20Alu	002543
Toyota	Landcruiser	5dr 4x4	2003	2009	RF20	002533	RF20Alu	002543
Toyota	Landcruiser Colorado	3dr 4x4	1996	2002	RF20	002533	RF20Alu	002543
Toyota	Landcruiser Colorado	5dr 4x4	1996	2002	RF20	002533	RF20Alu	002543

Bilmerke	Modell	Karosseri	Årsmodell		Takräcke – Stål		Takräcke – Alu	
			FRA:	TIL:	MODELL	ART.NR.	MODELL	ART.NR.
Toyota	Picnic	MPV	1997	2001	RF20	002533	RF20Alu	002543
Toyota	Previa	MPV	1990	2001	RF20	002533	RF20Alu	002543
Toyota	Previa	MPV	2001	2006	RF20	002533	RF20Alu	002543
Toyota	RAV4	3dr 4x4	2000	2006	RF20	002533	RF20Alu	002543
Toyota	RAV4	5dr 4x4	2000	2006	RF20	002533	RF20Alu	002543
Toyota	RAV4	5dr 4x4	2006	2012	RF20	002533	RF20Alu	002543
Toyota	Yaris Verso	MPV	2000	2006	RF20	002533	RF20Alu	002543
Vauxhall	Agila	5dr Halvkombi	2000	2008	RF20	002533	RF20Alu	002543
Vauxhall	Antara	5dr SUV	2007	on	RF20	002533	RF20Alu	002543
Vauxhall	Astra	5dr Kombi	1984	1991	RF20	002533	RF20Alu	002543
Vauxhall	Astra	5dr Kombi	1991	1998	RF20	002533	RF20Alu	002543
Vauxhall	Astra	5dr Kombi	1998	2004	RF20	002533	RF20Alu	002543
Vauxhall	Carlton	5dr Kombi	1986	1994	RF20	002533	RF20Alu	002543
Vauxhall	Frontera	3dr 4x4	1991	1998	RF20	002533	RF20Alu	002543
Vauxhall	Frontera	5dr 4x4	1991	1998	RF20	002533	RF20Alu	002543
Vauxhall	Omega	5dr Kombi	1994	1999	RF20	002533	RF20Alu	002543
Vauxhall	Omega	5dr Kombi	1999	2003	RF20	002533	RF20Alu	002543
Vauxhall	Sintra	MPV	1997	1999	RF20	002533	RF20Alu	002543
Vauxhall	Vectra	5dr Kombi	1996	2003	RF20	002533	RF20Alu	002543
Vauxhall	Zafira	MPV	1999	2005	RF20	002533	RF20Alu	002543
Volkswagen	Bora Variant	5dr Kombi	1998	2005	RF20	002533	RF20Alu	002543
Volkswagen	Caddy	Van	2010	2015	RF20	002533	RF20Alu	002543
Volkswagen	Caddy Maxi	MPV	2010	2015	RF20	002533	RF20Alu	002543
Volkswagen	Golf	5dr Kombi	1994	1998	RF20	002533	RF20Alu	002543
Volkswagen	Golf	5dr Kombi	1998	2005	RF20	002533	RF20Alu	002543
Volkswagen	Golf	5dr Kombi	2007	2009	RF20	002533	RF20Alu	002543
Volkswagen	Golf	5dr Kombi	2007	2009	RF20	002533	RF20Alu	002543
Volkswagen	Golf	5dr Kombi	2009	2012	RF20	002533	RF20Alu	002543
Volkswagen	Golf Plus	MPV	2009	on	RF20	002533	RF20Alu	002543
Volkswagen	Golf Plus Dune - Cross	MPV	2007	on	RF20	002533	RF20Alu	002543
Volkswagen	Passat	5dr Kombi	1981	1988	RF20	002533	RF20Alu	002543
Volkswagen	Passat	5dr Kombi	1988	1994	RF20	002533	RF20Alu	002543
Volkswagen	Passat	5dr Kombi	1994	1997	RF20	002533	RF20Alu	002543
Volkswagen	Passat	5dr Kombi	1997	2001	RF20	002533	RF20Alu	002543
Volkswagen	Passat	5dr Kombi	2001	2005	RF20	002533	RF20Alu	002543
Volkswagen	Passat	5dr Kombi	2005	2011	RF20	002533	RF20Alu	002543
Volkswagen	Passat	5dr Kombi	2011	2014	RF20	002533	RF20Alu	002543

Bilmerke	Modell	Karosseri	Årsmodell		Takräcke – Stål		Takräcke – Alu	
			FRA:	TIL:	MODELL	ART.NR.	MODELL	ART.NR.
Volkswagen	Passat	5dr Kombi	2014	on	RF50	002536	RF50Alu	002544
Volkswagen	Passat Alltrack	5dr Kombi	2012	2015	RF20	002533	RF20Alu	002543
Volkswagen	Passat Alltrack	5dr Kombi	2015	on	RF50	002536	RF50Alu	002544
Volkswagen	Polo	3dr Halvkombi	1990	1994	RF20	002533	RF20Alu	002543
Volkswagen	Polo Dune - Cross - Fun	5dr Halvkombi	2004	2008	RF20	002533	RF20Alu	002543
Volkswagen	Sharan	MPV	1995	2010	RF20	002533	RF20Alu	002543
Volkswagen	Tiguan	5dr 4x4	2007	2015	RF20	002533	RF20Alu	002543
Volkswagen	Touareg	MPV	2003	2010	RF20	002533	RF20Alu	002543
Volvo	240	5dr Kombi	1982	1993	RF20	002533	RF20Alu	002543
Volvo	850	5dr Kombi	1993	1996	RF20	002533	RF20Alu	002543
Volvo	740	5dr Kombi	1985	1990	RF20	002533	RF20Alu	002543
Volvo	760	5dr Kombi	1985	1990	RF20	002533	RF20Alu	002543
Volvo	745	5dr Kombi	1985	1990	RF20	002533	RF20Alu	002543
Volvo	765	5dr Kombi	1985	1990	RF20	002533	RF20Alu	002543
Volvo	940	5dr Kombi	1990	1996	RF20	002533	RF20Alu	002543
Volvo	960	5dr Kombi	1990	1996	RF20	002533	RF20Alu	002543
Volvo	V40	5dr Kombi	1996	2000	RF20	002533	RF20Alu	002543
Volvo	V40	5dr Kombi	2000	2004	RF20	002533	RF20Alu	002543
Volvo	V50	5dr Kombi	2004	2012	RF20	002533	RF20Alu	002543
Volvo	V60	5dr Kombi	2010	2017	RF25	002540	RF25Alu	002545
Volvo	V60 Cross Country	5dr Kombi	2010	2017	RF25	002540	RF25Alu	002545
Volvo	V70	5dr Kombi	2000	2007	RF20	002533	RF20Alu	002543
Volvo	V70	5dr Kombi	2007	on	RF20	002533	RF20Alu	002543
Volvo	V70 Cross Country	5dr Kombi	2001	2007	RF20	002533	RF20Alu	002543
Volvo	V90	5dr Kombi	1997	1998	RF20	002533	RF20Alu	002543
Volvo	XC60	MPV	2008	2017	RF25	002540	RF25Alu	002545
Volvo	XC70	MPV	2004	on	RF20	002533	RF20Alu	002543
Volvo	XC90	MPV	2002	2016	RF20	002533	RF20Alu	002543
Volvo	V90	5dr Kombi	2016	on	RF65	005752	RF65Alu	005753
Volvo	V90 Cross Country	5dr Kombi	2016	on	RF65	005752	RF65Alu	005753