


Jula item 009189, YK-AR1801

| NO. | Description | QTY | NO. | Description | QTY |
|------------|-----------------------------------|------------|------------|------------------------------|------------|
| 1 | Step bolt | 1 | 50 | Inner hex cylinder head bolt | 2 |
| 2 | Shaft sleeve | 2 | 51 | U seat | 2 |
| 3 | Washer | 3 | 52 | Spring washer | 8 |
| 4 | Nylon nut | 3 | 53 | Inner hex bolt | 4 |
| 5 | Cross pan head bolt | 4 | 54 | Adjustable end cap | 2 |
| 6 | Belt | 1 | 55 | Rear stabilizer | 1 |
| 7 | Display support | 1 | 56 | Aluminum guide rail end cap | 1 |
| 8 | Display | 1 | 57 | Nut plate | 1 |
| 9 | Cross pan head screw | 14 | 58 | Saddle | 1 |
| 10 | Washer | 12 | 59 | Nylon nut M8 | 5 |
| 11 | Footrest fixation block | 2 | 60 | Spring washer | 4 |
| 12 | Nylon nut M5 | 12 | 61 | Hex bolt | 4 |
| 13 | Fixation band | 2 | 62 | U block | 2 |
| 14 | Hex bolt | 4 | 63 | Hex bolt | 3 |
| 15 | Foot rest | 2 | 64 | Saddle support assembly | 1 |
| 16 | Rubber pad | 1 | 65 | Saddle support | 1 |
| 17 | Washer | 20 | 66 | Wheel sleeve | 6 |
| 18 | Wheel | 2 | 67 | Bearing 608Z | 6 |
| 19 | Inner hex bolt | 2 | 68 | Belt wheel shaft | 1 |
| 20 | Inner hex countersunk bolt M8x20 | 2 | 69 | Bearing 6300-2RS | 1 |
| 21L/R | Foot rest support | 1pair | 70 | Circlip for hole | 1 |
| 22 | Sphere end cap | 2 | 71 | Shaft for belt fixation | 1 |
| 23 | Nylon nut | 1 | 72 | Friction belt wheel | 1 |
| 24 | Washer | 2 | 73 | One way bearing | 1 |
| 25 | Mainframe | 1 | 74 | Belt wheel | 1 |
| 26 | Wheel | 3 | 75 | YK-AR1801 buckle | 2 |
| 27 | Extension wire | 1 | 76 | PC plate | 1 |
| 28 | Hex bolt | 1 | 77L/R | Chain cover | 1pair |
| 29 | Cross pan head self-drilling srew | 33 | 78 | Bearing 6000-2RS | 1 |

Jula item 009189, YK-AR1801

| | | | | | |
|-------|--|-------|-----|------------------------------|---|
| 30 | Inner hex pan head bolt | 2 | 79 | Rubber gasket ring | 1 |
| 31 | Handlebar | 1 | 80 | Hex bolt | 2 |
| 32L/R | Front stabilizer end cap | 1pair | 81 | Washer | 1 |
| 33 | Bolt for chain adjustment | 2 | 82 | Bearing 6004-2RS | 2 |
| 34 | Front stablizer | 1 | 83 | Corrugated washer | 1 |
| 35 | Wire holder | 1 | 84 | Shaft sleeve | 2 |
| 36 | Knob | 1 | 85 | Magnet plate | 1 |
| 37 | Washer | 1 | 86 | Corrugated washer | 1 |
| 38 | Strengthen column | 1 | 87 | Washer | 1 |
| 39 | Sensor wire | 2 | 88 | Bush for spring | 1 |
| 40 | Aluminum guide rail | 1 | 89 | Round magnet | 2 |
| 41 | Guide rail sleeve | 2 | 90 | Pressing spring | 1 |
| 42 | Limited column | 1 | 91 | Washer | 4 |
| 43 | Cross pan head countersunk screw | 3 | 92 | Spring washer | 4 |
| 44 | Wire holder | 1 | 93 | Inner hex cylinder head bolt | 4 |
| 45 | Pulse box | 1 | 94 | Handlebar fixation plate | 1 |
| 46 | Nylon nut M6 | 2 | 95 | Bearing circle | 1 |
| 47 | Nut | 2 | 96 | Resistance controller | 1 |
| 48 | Cushion pad | 2 | 97 | Round end cap | 2 |
| 49 | Round magnet | 1 | 98 | Foam | 1 |
| 99 | Bearing 16003-2RS | 2 | 107 | Aluminum plate | 1 |
| 100 | Corrugated washer | 1 | 108 | Magnet air wheel | 1 |
| 101 | Shaft ring | 2 | 109 | Curl spring | 1 |
| 102 | Shaft of band wheel | 1 | 110 | Hex thin nut | 4 |
| 103 | Bearing 6000-ZZ | 1 | 111 | L chain adjusting bolt | 1 |
| 104 | Belt pulley | 1 | 112 | PC cover | 1 |
| 105 | Multi-V belt | 10 | 113 | Corrugated washer | 1 |
| 106 | Cross countersunk head self-drilling screw | 5 | 114 | Band wheel outer end cap | 1 |

Jula item 009189, YK-AR1801



Jula item 009189, YK-R1801

