


Jula item 000903, Sunseeker BCS43 43cc HPP brush cutter engine parts list

No.	SK ERP code	Parts description in English	Qty
1	T.BCS45-08	Decorating plate	1
2	GB/T 70.1	M5x14 screw	6
3	GB/T 70.1	M6x30 screw	1
4	GB/T 29.2	M5x20 screw	4
5	T.BCS45.03	Output base assy.	1
5,1	T.BCS45.03-1	Output base	1
5,2	GB/T 276	Bearing 6202	2
5,3	T.BCS45.03-2	Double bearig catch plate	1
5,4	GB/T 894.2	φ15 checking ring	1
5,5	GB/T 893.1	φ35 checking ring	1
5,6	T.BCE43A.02-3	Rubber cover	1
5,7	T.BCE43A.02-2	Connecting cover	1
5,8	GB/T 893.1	φ45 checking ring	1
6	T.BCS45-07	Connecting plate	1
7	5003,3321	Screw axes	2
8	T.BCB33-063	Wave washer	2
9	T.BCB33.10	Clutch	1
10	T.BCB33-064	Washer B	3
11	GB/T 6185.1	M8 nut	2
12	GB/T 93	Spring washer 8	1
13	GB/T 97.1	Flat washer 8	1
14	5011,31903	Fly wheel	1
15	GB/T 70.1	M5x20 screw	14
16	T.BCS45.08	Ignition coil	1
17	GB/T 70.1	M5x30 screw	4
18	GB/T 119.2	Round pin Φ4x10	2
19	T.BCE43-005	Front-half crankshaft case	1
20	GB/T 9877.1	Oil seal TC15x30x7	1
21	GB/T 276	Bearing 6202/P6	2
22	5011,31905	Crankshaft	1
23	GB/T 9877.1	Oil seal TC12x22x7	1
24	GB/T 1099	Half-round key3*5*13	1
25	JB/T 7918	Bearing,needleKBK101315.5	1
26	324010101	Piston pin check ring	2
27	5004,33209	Piston pin	1
28	5011,33203	Piston	1
29	5004,33206	Piston ring	2
30	T.BCB43-004	Cylinder gasket	1
31	T.BCS43-01	Cylinder	1
32	5009,31501	Spark plug	1
33	5011,34601	Muffler gasket assy	1
34	T.BCS45.05	Muffler assy	1
35	T.BCE45.05-3	Muffler steel cover	1
36	GB/T 97.1	Flat washer 6	2
37	GB/T 70.1	M6x60 screw	2
38	T.BCS45-14	Inlet gasket	1
39	T.BCS45-03	Inlet pipe	1
40	T.BCS45-30	Foam bar	1
41	324080301	flat washer 5x15x1.2	1
42	GB/T 818	M4x8 screw	3
43	319060101	Primer bulb	1
44	T.BCS45-25	Output fuel hose	1
45	T.BCS45-28	Output fuel hose spring	1
46	GB/T 70.1	M5x20 screw	4
47	T.BCS45-13	Carburator gasket	1
48	T.BCS45.04	Carburator	1
49	80200336-01	Air filter base	1
50	80700135-01	flat washer 5	2
51	80700030-05	M5x50 screw	2
52	80700030-05	Air filter inlet plate	1
53	80400267-01	Paper filter	1
54	80300441-01	Air filter outer cover	1
55	80700023-12	M5x25 hex screw	2
56	T.BCB43-005	Crankshaft gasket	1
57	GB/T 119.2	Round pin B5x10	2

Jula item 000903, Sunseeker BCS43 43cc HPP brush cutter engine parts list

No.	SK ERP code	Parts description in English	Qty
58	T.BCE43-006	Back-half crankshaft case	1
59	T.BCE33B.09	Starter catch plate assy	1
60	T.BCS45.01	Starter assy	1
60,1	T.BCS45.01-1	Starter main cover	1
60,2	T.BCE52T.12-11	Starter guard rope	1
60,3	341540101	Starter grip	1
60,4	T.BCB33.08-4	Starter grip cover	1
60,5	T.BCS45.01-2	Starter inner plate	1
60,6	T.BCE33B.03-8	Starting coil spring	1
60,7	T.BCE52T.12-6	Starting rope	1
60,8	T.BCE33B.03-4	Starter rope pully	1
60,9	T.BCE33B.03-7	Starting torsion spring	1
60,10	T.BCE33B.03-5	Starter pully	1
60,11	T.BCD43.03-8	Flat washer	1
60,12	GB/T 818	M5x12 screw	1
61	GB/T 845	ST4.8x15-H-C screw	2
62	GB/T 845	ST3x9-H-C Screw	4
63	T.BCS45-16	Air guide plate	1
64	GB/T 70.1	M5x16 screw	3
65	T.BCS45-01	Engine case cover	1
66	T.BCS45-10	Steel checking ring	1
67	T.BCS45-09	Primer bulb cap	1
68	T.BCS45-06	Top cover	1
69	T.BCS45.02	Fuel tank assy	1
70	T.BCS45-29	Returing fuel hose spring	1
71	T.BCS45-05	Under engine base cover	1



Jula item 000903, Sunseeker BCS43 43cc HPP brush cutter working shaft parts list with price

No.	SK ERP code	Parts description in English	Qty/unit engine
1	T.BCE43B.05	Aluminum working shaft φ28x1500 assy	1
1,1	T.BCE43B-8	Aluminum working shaft φ28x1500	1
1,2	T.BCE43B.06	Oil-retaining bearing and cover	6
2	T.BCD43-3	Hardness axesφ8x762	1
3	80100715-02	Gear case assy	1
5	GB/T 70.1	M5x16 screw	1
6	GB/T 70.1	M6x30 screw	1
7	T.BCB33.18C1	Protection guard assy.	1
7,1	T.BCB33.18C-3	Protection guard	1
7,2	T.BCB33.18C-2	Protection guard under cover	1
7,3	GB/T 845	ST4.2x10-H-F screw	1
7,4	5008,34103	Guard blade holder	1
7,5	GB/T 845	ST4.2x16-H-F screw	2
7,6	GB/T 845	ST4.8x20-H-F hanf thead screw	1
7,7	T.BCB33.18C-1	Nylon line cutting blade	1
8	GB/T 70.1	M6x25 half thead hex screw	4
9	T.BCS45.09	Anti-vibration handle assy.	1
9,1	T.BCS45.09-1	Anti-vibration handle	1
9,2	T.BCS45.09-2	Aluminum fixing seat	1
9,3	T.BCS45.09-3	Fixing circle	1
9,4	T.BCS45.09-4	Spring fixing seat A	2
9,5	T.BCS45-23	Handle bar fixing under block	1
9,6	T.BCS45-24	Handle bar fixing upper block	1
9,7	T.BCS45.09-7	Knob spring	1
9,8	T.BCS45.09-5	Spring fixing seat B	2
9,9	T.BCS45-22	Anti-vibration rubber	2
9,10	T.BCS45.10	Knob assy.	1
9,11	T.BCS45-21	Anti-vbration handle plate	1
9,12	T.BCS45.09-6	Spring	2
9,13	GB/T 70.1	M5x12 screw	1
9,14	GB/T 845	ST4.8x16-H-C Screw	4
9,15	GB/T 845	ST4.2x16-H-C Screw	1
10,1	T.BCB52.04-1	Handle tube	1
10,2	T.BCB52.04-5	Lfft handle (without tube)	1
10,3	T.BCB52.04.3	Right handle (with cable)	1
10,4	GB/T 9074.3	M5x35 screw	1
11	330700353-01	Aluminum protection guard	1
12	5003,33303	3T blade	1
13	5003,34122	3T blade cover	1
14	T.BCB33.14B	nylon head (with φ2.8 line)	1
15	T.BCE43B-26	24T saw blade (9")	1
16	T.BCE43B-25	Saw blade cover	2