











**optional part**

101



<b>EX_ID</b>	<b>Spare Parts Code</b>	<b>Part Name(EN)</b>	<b>Qty.</b>
1	12531000001579	Glass door assembly	1
1.1	17131000000027	Display control panel	1
1.2	12131000001139	Box cover	1
1.3	12131000010316	Door gasket assembly of refrigerator	1
1.4	12131000006211	Shaft sleeve	1
1.5	12231000006558	Stopper	1
3	12931000000274	Steel wire wine rack	1
7	12931000000286	Steel wire wine rack	4
8	12131000005132	Hinge cover	1
9	11303305000004	tapping locking screw	10
10	12931000000552	Upper hinge	1
15	17431000000094	LED lamp	1
16	12131000001178	Box cover	1
17	15733000000261	Refrigerator rollbond evaporator	1
18	12231000006997	Lower hinge assembly	1
19	12131000000999	Levelling feet	1
20	12831000008809	Cabinet assembly	1
21	17431000001087	Power cord	1
22	12131000004317	Drain tray	1
24	17131000000142	Main control board	1
25	11101010014213	Fixed speed reciprocating compressor	1
25.1	12031000001062	Starter	1
25.2	12031000001294	Protector	1
26	12231000005828	Compressor mounting panel	1
101	12231000005661	Compressor back cover	1