


Jula item 018517



SPAREPART LIST CDJ085C

NO.	PART NO.	Name	QTY
1	CDJ085B.03-06	Depth limit lock handle	1
2	CDJ085B.03-05	Depth pointer	1
3	CDJ085B.03-02	Depth limit lock block	1
4	CDJ085B.03-04	Depth limit lock pin	1
5	GB119.2-2000	Cylindrical pin Φ 3x16	1
6	CDJ085C-05	Aluminum cap	1
7	CDJ085C-09	Saw blade guard	1
8	CDJ085B.04-01	Movable shield	1
9	CDJ085B.04-02	Movable guard limit pin	1
10	CDJ085B-25	Saw blade screw	1
11	CDJ085B-24	Saw blade pressing plate	1
12	CDJ085B-29	Φ 85 TCT 30 tooth saw blade	1
13	CDJ085B-23	Saw blade seat	1
14	GB894.1-86	Circlip for shaft 22	1
15	GB893.1-86	Circlips for holes 26	1
16	CDJ085B.02-11	Gear box dust baffle	1
17	CDY210AL-54	Oil bearing	1
18	CDJ085B.02-01	Gearbox	1
19	CDJ085B-27	Laser	1
20	CDJ085B-26	Laser block	1
21	GB73-85	Slotted flat point set screws M4x6	1
22	GB818-2000	Cross recessed pan head screws M4x10	1
23	CDJ085B-21	Movable guard lock pin	1
24	CDJ085B.02-08	Output shaft	1
25	GB818-2000 M4x12 +GB859 -874+GB848-854	GB818-2000 cross recessed pan head screw M4x12+GB859-87 light spring washer 4+GB848-85 small washer 4	10
26	CDJ085B.02-07	Big bevel gear	1
27	GB276-94	608-2RS bearing (8x22x7)	1
28	CDJ085B.02-02	Gear box cover	1
29	CDJ085B.01	Shaft lock	1
30	GB896-86	5 open retaining ring	1
31	CDJ085B.02-06	Small bevel teeth	1
32	GB276-94	6000-2RS bearing (10x26x8)	2
33	CDJ085B.02-05	helical gear	1
34	GB276-94	608-2RS bearing (8x22x7)	1
35	CDJ085B.02-04	transmission shaft	1
36	CDJ085B.02-03	Bearing chamber	1
37	GB6561-86	Cross recessed countersunk head tapping locking screws M4x12	2
38	GB818-2000 M4x30 + GB859-87 4 + GB848-854	GB818-2000 cross recessed pan head screw M4x30+GB859-87 light Spring washer 4+GB848-85 small washer 4	4
39	CDJ085B-20	Windshield	1
40	CDJ085B.09-03	Wind leaf	1
41	CDJ085B.09	Armature assembly	1
42	GB276-94	607-2RS bearing (7x19x6)	1
43	CDJ085B.10	Stator assembly	1

SPAREPART LIST CDJ085C

NO.	PART NO.	Name	QTY
44	CDY190E-12	Bearing bush	1
45	CDJ085C-03	chassis	1
46	CDJ085C-04	Back cover	1
47	CGN310D-05	Power cord sheath	1
48	CDJ085B.06	Carbon brush assembly	2
49		Terminal HYT-230 (double row)	1
50	CDJ085B-09	Micro Switch	1
51	CDJ085B-16	Battery box cover	1
52	CDJ085B.05-01	Battery box	1
53	CDJ085B.05-02	Battery reed	2
54	CGN280A-16	Crimping board	1
55	CDJ085B-10	Switch button	1
56	CDJ085B-15	Anti-self-locking button push rod	1
57	CDJ085B-14	Anti-self-locking button	1
58	CDJ085B-13	Laser switch	1
59	CDJ085B-12	Laser switch button	1
60	GB846-85	Cross recessed countersunk head tapping screws ST4.2x10-F	1
61	GB845-85	Cross recessed pan head tapping screws ST4.2x13-F	2
62	CDJ085C-01	Left handle	1
63	CDJ085C-02	Right handle	1
64	CDJ085B-07	Power indicator cover	1
65	CDJ085B-08	Power Indicator	1
66	GB845-85	Cross recessed pan head tapping screws ST4.2x16-F	12
67	GB6561-86	Cross recessed countersunk head tapping locking screws M4x1	2
68	CDJ085B-02	Gearbox bracket	1
69	CDJ085B.02-09	Gearbox shaft	1
70	CDJ085B-22	Torsion spring	1
71	GB889.1-2000	Type 1 hexagon lock nut with non-metallic insert M6	1
72	CDJ085C-10	Bottom plate	1
73	GB6561-86	Cross recessed countersunk head tapping locking screws M4x8	4
74	CDJ085B.07	Ruler assembly	1
75	CDJ085C-07	Dust outlet connector	1
76	CDJ085C-06	Dust outlet	1
77	CDJ085C-08	Dust connecting pipe	1