


Z1C-DS-25K SPARE PART VIEW



Z1C-DS-25K SPARE PART LIST

NO	NAME	QTY
1	Rubber head	1
2	Ring 17*1.6	1
3	Ring 19.2*26.5*2	1
4	Spin sleeve	1
5	Spring 25.5*1.6*4*45	1
6	Ring 47	3
7	oil seal	1
8	Ring 28*1.6	2
9	Bearing61906	1
10	X-ring 25*1*4	1
11	Ball7.14	5
12	sleeve	1
13	impect Ball	1
14	X-ring 13*1*4	1
15	Running pulley5*5	3
16	cylinder	1
17	pin3*2.5*18	2
18	soket head caps screw M5*22	4
19	cylinder house	1
20	Ring 30.5*40.5*1.5	1
21	Spring 33*3*6*60	1
22	gear 34th	1
23	hammer	1
24	O-ring 19*3.1	2
25	position	1
26	pin 6*24	1
27	Connect Rod	1
28	steel sleeve 8*12*10	1
29	Bearing 30*47*9	1
30	Gear Box	1
31	Oil cover	1
32	O-ring 31.5*2	1
33	O-ring 11*2.2	1
34	knob shaft	1
35	washer 16*12*0.3	1
36	Ring 17	1
37	buttor	1
38	spring 0.6*4.5*17.5	1
39	knob	1
40	self-tappings screw M4*12	1
41	oil seal F19*28*4.5	1
42	Gear 10th	1
43	Ring15*19*4.7	1
44	Bearing 6002	1
45	Ring14.1*19*0.5	1
46	Gear 39:4	1
47	trippinc fixed plate	1

Z1C-DS-25K SPARE PART LIST

NO	NAME	QTY
48	Ring 12.5*1	1
49	Ball 5	8
50	trippinc active board	1
51	spring 14.2*9*0.5*2.7	2
52	Nut M10*0.75	1
53	Bearing627	1
54	crankshaft 30A	1
55	Bearing 6003	1
56	Ring 28.5*34.5*1	1
57	Ring 35	1
58	Ring 17	1
59	Spring 7.8*1.2*11*33	1
60	pin A5*5*22	1
61	Gear 27th	1
62	Pin 7*19	1
63	Neddle bearing HK1201	1
64	Steel sleeve 22*26*9	1
65	self-tappings screw 3*7	1
66	inner cover	1
67	knob	1
68	o-ring 8.5*2	1
69	Bearing 6000	1
70	Rotor	1
71	Bearing608	1
72	Fan guide	1
73	self-tappings screw 3.9*55	2
74	stator	1
75	spring	2
76	soket head caps screw M5*50	4
77	main case	1
78	Brush cover	2
79	Brush	2
80	Brush cover	2
81	self-tappings screw ST3.9*16	7
82	Handle	1
83	self-tappings screw ST3.9*25	2
84	switch	1
85	self-tapping screw	2
86	cable Board	1
87	capacitance	1
88	inductance	1
89	Cable holder	1
90	cable	1
91	self-tapping screw M5*22	2
92	Handle	1
93	hoope	1
94	T bolt M8*36	1

Z1C-DS-25K SPARE PART LIST		
----------------------------	--	--

95	Bracket buttor	1
96	Spring W7.2*0.9*15	1
97	Bracket	1
98	Auxiliary handle	1