

Jula item 004841

HKPCS06 SPARE PARTS LIST

no	description	pcs/unit	no	description	pcs/unit
1	chain wheel sheath	1	48	Adjusting screw	1
2	chain	1	49	Guide positioning column	1
3	guide board	1	50	Pipe joint locking knob	1
4	Cylindrical sealing ring	1	51	Hexagon socket screw	2
5	Oil outlet joint	1	52	Capacitor	1
6	short petroleum pipe line spring	1	53	common mode inductor	1
7	short petroleum pipe line	1	54	wiring terminal	1
8	tapping screw ST3X10	3	55	Crimping board	3
9	oil pump	1	56	tapping screw ST4X14	3
10	long petroleum pipe line spring	1	57	Bushing	1
11	long petroleum pipe line	1	58	Power cord	1
12	Oiler	1	59	tapping screw ST4X14	15
13	Left house	1	60	right handle	1
14	O-ring seal	1	61	cushion of handle	1
15	Oiler cover	1	62	left handle	1
16	Deep groove ball bearing 6000ZZ	1	63	main button	1
17	Large bevel gear	1	64	rotary button spring	1
18	Flat key	1	65	Microswitch 1	1
19	Output shaft	1	66	push button	1
20	Deep groove ball bearing 608ZZ	3	67	push button spring	1
21	Hexagon bolt	2	68	Strap buckle	1
22	Hexagon locking nut M5	5	69	Buckle strap lock	1
23	Bevel pinion	1	70	foam	1
24	Rotor	1	71	Aluminum tube	1
25	Carbon brush	2	72	Rivet	2
26	Brush holder	2	73	Pipe joint	1
27	Brush contact sheet	2	74	Aluminum tube	1
28	Stator	1	75	Aluminum tube cover(right)	1
29	Rotary button(down)	1	76	Aluminum tube cover(left)	1
30	Rotary handle(left)	1	77	Festen sitz deckplatte	1
31	Rotary line catch	1	78	Plug spring holder	1
32	Insert holder	1	79	spring line	1
33	Rotary handle(right)	1	80	Hexagon locking nut M6	1
34	Hexagon socket head cap screwM5X16	4	81		
35	Hexagon socket head cap screwM5X40	1	82		
36	Rotary button(up)	1	83		
37	Rotary button spring	1	84		
38	Right house	1	85		
39	tapping screw ST4X16	11	86		
40	Sprocket wheel	1	87		
41	Circlip for shaft	1	88		
42	Sprocket cover	1	89		
43	Hexagon flange nut M8	2	90		
44	Dichtung	1	91		
45	O-ring seal	1	92		
46	tapping screw ST4X16	1	93		
47	Guide plate	1	94		