



SE Ingredienser i tvätt- och rengöringsmedel
NO Ingredienser i vaske- og rengjøringsmidler
PL Składniki detergentów
EN Ingredients in detergents

Screen cleaner kit for TV, tablet, smartphone, PC

Item No: 004689

Ingredients	CAS No	Concentration
Pure water	7732-18-5	94,4%
Propylene glycol n-propyl ether	1569-01-3	3%
Carob gum	9000-40-2	1,5%
Decylglucoside	68515-73-1	1%
Potassium sorbate	590-00-1	0.03%
Methyl-4-hydroxybenzoate	99-76-3	0.02%

SE Ingredienserna finns med i förteckningen med sitt INCI namn (internationella nomenklaturen för kosmetiska ingredienser) eller med sitt kemiska namn, om INCI namn saknas.

NO Ingredienserne er oplyst i henhold til deres INCI navn (International Nomenclature of Cosmetic Ingredients) eller ved deres almindelige navn, hvis der ikke findes et INCI navn.

PL Każdy składnik jest opisany przez nazwę INCI (International Nomenclature of Cosmetic Ingredients) lub przez nazwę chemiczną w przypadku braku INCI.

EN Each ingredient is described by its INCI name (International Nomenclature of Cosmetic Ingredients) or if no INCI name is available, then the ingredient is described by its chemical name.

INCI/CAS information: <http://ec.europa.eu/consumers/cosmetics/cosing/>

www.jula.com

Postal address	Visiting address	Phone:
Jula AB	Jula AB	0511-246 00
Box 363	Julagatan 2	Fax:
532 24 Skara	532 37 Skara	0511-246 21