



explred no.	spare part name	Material/s in component	number
1	back cover	ABS	1
2	left support plate	aluminium profile	1
3	right support plate	aluminium profile	1
4	semicircle head square neck bolts M8×16		7
5	locknut M8		7
6	right cover	Q235	1
7	left cover	Q235	1
8	Nylon square neck connector	PA6	17
9	extention table	Q235	1
10	cylinder		1
11	seal ring 43.7×3.55	Nitrile rubber	1
12	piston		1
13	left reinforcing rib	Q235	2
14	hexagon socket head cap screws M8×16		3
15	flat Washer 8		3
16	right reinforcing rib	Q235	2
17	big spring		1
18	nut M14		4
19	stud M10X642		4
20	lock bolt M6		2
21	working table	Q235	1
22	front support foot	Q235	1
23	cover for cylinder		1
24	seal ring 6×1.8	Nitrile rubber	1
25	air bleed screw M6		1
26	bonded washer 14	Nitrile rubber	1
27	piston rod		1
28	plug screw M14×1.5		1
29	hold-down nut for handle	Q235	1
30	handle	Q235	1
31	acorn nut M10		3
32	back support foot	Q235	1
33	handle cover	Q235	1
34	compound gasket 10	Nitrile rubber	1
35	small shaft		1
36	manifold block		1
37	seal ring 55x3.1	oil resistant rubber	1
38	oral pad	oil resistant rubber	1
39	small spring for gear pump		1
40	Hexagonal countersunk head screw M8x8		1
41	inner sleeve		1
42	spring		1
43	screw M16X1.5		1
44	wheel	Butyl rubber	2
45	soket head cap screw M10X25		4

explred no.	spare part name	Material/s in component	number
46	nut M10		4
47	plate for pusher		1
48	plastic spacer		1
49	support for working table	Q235	1
50	bolt M8X55		6
51	pump case		1
52	seal ring 10x2.65	Nitrile rubber	2
53	seal ring 56x41	Nitrile rubber	2
54	dummy plate		1
55	gear		2
56	ball S ϕ 2.5		1
57	shaft sleeve		2
58	pin 8x25		2
59	pump frame		1
60	outer hexagon bolt M5X25		3
61	left foot cover	Butyl rubber	1
62	right foot cover	Butyl rubber	1
63	spring washer 5		3
64	flat Washer 5		3
65	framework oil seal 15X26X7.9		2
66	Motor		1
67	Pin 2.5x6		1
68	switch box	ABS	1



R018234 Strömbrytare



R026690 Ventil



R026691 Hjul. OBS! Pris per styck.



R026692 Motor